

# Level sensor tester GPR 4, Anode tester AT1



## Level sensor tester GPR 4

**Application** For use with storage tanks for fuel oils and diesel fuels. Not permitted for use in hazardous areas and not for level sensors which are installed in tanks containing hazardous media.

**Description** Simple level sensor tester with connector, suitable for all level sensor fittings. A signal lamp indicates function or error. Battery-operated. Delivery with level sensor connection fitting, also suitable for level sensor with brass fitting.



**i**

See the DOMESTIC TECHNOLOGY catalogue for the complete range of level sensors and anodes.



## Anode tester AT1

Tester for consumption check of anode I or isolated standard sacrificial anodes.

- Handheld tester with 4-level LED indication
- Fast and easy indication of the condition of the anode
- Reliability of the water heater due to preventive maintenance – consumed anodes are replaced in good time

5

DG: H, PG: 4	Part no.	Price €
<b>Level sensor tester GPR 4</b>	<b>62301</b>	
<b>Anode tester AT1</b> for anode I	<b>69842</b>	

